



IRONMAX PRO®



Streutabellen für BOGBALLE MODELL M1

Arbeitsbreite 10 m							
PTO: 540 Umdrehungen/Minute 250 Umdrehungen/Minute							
10-050		E1		1-2			
	kg/ha				kg/min		
	8 km/h	10 km/h	12 km/h	14 km/h		+/- °	+/- cm
1,0	3	2	2	2	0,4	-4	-6
1,5	10	8	7	6	1,4	-4	-6
2,0	21	17	14	12	2,9	-4	-6
2,5	29	23	19	16	3,8	-4	-6
3,0	36	29	24	20	4,8	-4	-6
3,5	43	35	29	25	5,8	-4	-6
4,0	51	40	34	29	6,8	-4	-6
4,5	58	46	38	33	7,7	-4	-6
5,0	62	49	41	35	8,2	-4	-6
5,5	71	56	47	40	9,4	-4	-6
6,0	76	61	51	43	10,2	-4	-6

	D-Indikator						
	< 2 mm	2-3,3 mm	3,3-4,75 mm	> 4,75 mm			
	A	B	C	D			
kg	%				kg/l	kg	l/min
1,3	1	99	-	-	0,83	2,94	11

Weitere Informationen finden Sie unter www.bogballe.com

www.agrar.bayer.de/IronmaxPro



IRONMAX PRO®



Streutabellen für BOGBALLE MODELL M1

Arbeitsbreite 12 m							
PTO: 540 Umdrehungen/Minute 250 Umdrehungen/Minute							
12-050		E1		1-2			
	kg/ha				kg/min		
	8 km/h	10 km/h	12 km/h	14 km/h			
1,0	3	2	2	1	0,4	-4	-6
1,5	9	7	6	5	1,4	-4	-6
2,0	18	14	12	10	2,9	-4	-6
2,5	24	19	16	13	3,8	-4	-6
3,0	30	24	20	17	4,8	-4	-6
3,5	36	29	24	20	5,8	-4	-6
4,0	42	34	28	24	6,8	-4	-6
4,5	48	38	32	27	7,7	-4	-6
5,0	51	41	34	29	8,2	-4	-6
5,5	59	47	39	33	9,4	-4	-6
6,0	63	51	42	36	10,2	-4	-6

	D-Indikator						
	< 2 mm	2-3,3 mm	3,3-4,75 mm	> 4,75 mm			
	A	B	C	D			
kg	%				kg/l	kg	l/min
1,3	1	99	-	-	0,83	2,94	11

Weitere Informationen finden Sie unter www.bogballe.com

www.agrar.bayer.de/IronmaxPro



Streutabellen für BOGBALLE MODELL M1



Arbeitsbreite 15 m							
PTO: 540 Umdrehungen/Minute 300 Umdrehungen/Minute							
15-050		E1		1-2			
	kg/ha				kg/min	+/- °	+/- cm
	8 km/h	10 km/h	12 km/h	14 km/h			
1,0	2	1	1	1	0,4	-4	-6
1,5	7	5	4	4	1,4	-4	-6
2,0	14	11	9	8	2,9	-4	-6
2,5	19	15	12	11	3,8	-4	-6
3,0	24	19	16	13	4,8	-4	-6
3,5	29	23	19	16	5,8	-4	-6
4,0	34	27	22	19	6,8	-4	-6
4,5	38	31	25	22	7,7	-4	-6
5,0	41	33	27	23	8,2	-4	-6
5,5	47	37	31	27	9,4	-4	-6
6,0	51	40	34	29	10,2	-4	-6

	D-Indikator						
	< 2 mm	2-3,3 mm	3,3-4,75 mm	> 4,75 mm			
	A	B	C	D			
kg	%				kg/l	kg	l/min
1,3	1	99	-	-	0,83	2,94	11